

Assembly Manual



What's In The Box


Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Rod



Crossbar



Dual Tripod Holder
With Clamp



2 x Clamps with flower knob

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

Dual Tripod Holder Setup

Cross Bar Mounting


- Loosen and open the ratchet knob of the clamp.



- Align and attach the clamp with the rod and tighten it using the ratchet knob.



- Similarly, attach the second clamp to the rod as shown in the image.



Clamp Mounting

- Loosen the first clamp knob and remove it.




- Similarly, remove the second knob.



- Insert the first knob into the cross bar.
- Attach the clamp to the cross bar and secure it using the knob.



- Similarly, insert the second knob.



Clamp Mounting

- Loosen the clamp knobs and remove them.




- Keep the knobs aside.



- Insert the first knob into the cross bar.
- Attach the clamp to the cross bar and secure it using the knob.



- Insert the second knob securely.




Rod Mounting

- Loosen the ratchet knob of the clamp and open it.



- Insert the rod into the clamp's hole on the crossbar.
- Close the top clamp to secure it.



- Re-tighten the ratchet knob of the clamp.



Dual Tripod Holder Mounting

- Loosen the ratchet knob and open the clamp of the Dual tripod holder.



- Mount the Dual tripod holder on the rod and re-tighten the ratchet knob to secure it.



- Dual tripod holder is attached to the cart and ready to use.



Stand Mounting (Not Included)

- Mount the Tripod Stand (Not included) on the tripod holder.

NOTE: Tripod Holder for Camera Cart is a perfect add-on accessory to carry or store two full-size tripods on the cart.



YOUR PROAIM DUAL TRIPOD HOLDER FOR CAMERA CART ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer a one-year warranty for our products from the date of purchase. Within this period, we will repair it without charge for labor or parts. The warranty doesn't cover transportation costs, nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subject to inspection and evaluation by us.

Liability: We are not liable for damage caused by products we do not supply or from mishandling in transit, accident, misuse, neglect, or lack of care of the product or service by anyone other than our company.

Contact Us: If you are dissatisfied, please contact us immediately. We promise our utmost support and care until you use our product.